


ENCLOSURE WITH KNOB















PUSH BUTTON-SWITCH

- SERIES 1273



screws to fix the PCB.

Enclosure with knob, for wall mounting, suitable for room thermostats etc. A knob fits among others

trimmer PCH 215/30 and another knob for encoder can be used. See www.Bernic.dk. Standard colour is white/black but other colours can be supplied upon request. PCB and packing are available.Base part available with cold pressfixing taps or for selftapping

	TECHNICAL DATA:	
	Top part: Base part: Colour:	Cycoloy C 2800 Lexan 940 White/black (RAL9010/RAL9005)
	Temperature range: Self-extinguishing: Knob:	-30 - + 90 °C Acc. to UL94-V0 Cycoloy C 2800
		7.5 23.7
[TYPE 630	ORDER CODE:
	Top part	p/n 0630000600
[Base part incl. 2 screws	p/n 0669000609
	Base part w.integrated spacer	p/n 0699000612
	PCH 215/30 10k trimmer	p/n 0207220103
	Packing	p/n 2068601004
	Raw PCB	p/n 4999000600
	Knob for encoder	p/n 7445501607
	Knob without print	p/n 066900 1603
	Knob with grey print	p/n 0669080603
	Knob with red print	p/n 0669020603
	Knob with black dot	p/n 0669081603
	Light conductor	p/n 4972001258
	Push button switch	p/n 4955127313
C	Rocker switch - 28V DC	p/n 1441210212
l		

1273

7.5

Push switches for series 300/600/900 with snap-in terminals and knob. Knob available in several colours upon request.

Colour:	White
Contact rating:	50 m A/12V DC
Contact resistence:	100 mW
Life time:	Min. 100.000 operations
Operating force:	100 g